TX–6

ultra-portable pro-mixer
and audio interface.



all features

TX–6 power up title screen.

home screen / master level.

home screen / master level. FX I and FX II active.

home screen. precise level indicator for faders.

tempo.

system menu.

mono. left input signal mixed to both channels.

stereo. default left and right stereo mix.

split. left and right signals combined, for when using a splitter cable.

main detection. when a plug is inserted into the main output.

aux detection. when a plug is inserted into the aux output.

cue detection. when a plug is inserted into the cue output.

low pass / high pass filter.

3-band equalizer high / mid / low.

compressor.

input gain.

panning left and right.

solo mode. solos selected channel and mutes others.

mute mode. mutes selected channel.

solo momentary.

mute momentary.

equalizer. the default layout for the parameter knobs.

custom. a configu-rable scheme for all potentiome-ters

track. individual potentiome-ter settings. use the track buttons to configure.

synth. synth controls for the built-in syntheziser and drum machine.

effects active on main screen.



effect send level for FX I.

effect return level for FX I.

chorus presets: subtle, medium, strong.

reverb presets: light, small, medium, large, drone.

delay presets: 1/8, 1/4, 1/2, 2/3, 3/4, 1, 3/2, warp, mash.

tremolo.

freeze.

tape presets: stop1, stop2, pong.

filter.

distortion presets: push, drive, blow, dstroy.

crush presets: shape, bend, chip, bit.

tempo main screen. clock is stopped.

tempo main screen. clock is running using internal tempo.

clock is running and showing a blinking beat indicator. sync out is active.

clock is running and showing a blinking beat indicator. sync in is active

main auxiliary level.

individual auxiliary send per channel with track button.

auxiliary pre-fader selection.

auxiliar post-fader selection.

cue out volume.

cue mode cue.

cue mode main.

mic volume 0-100.

mic gain.

mic effect.

instrument tuner.



vu meter settings pre fader.

vu meter settings post fader.

limiter off.

limiter on.

track memory on.

track memory off.

2+2 channel usb interface.

12 channel usb input, mixed with the analog inputs.

12 channel usb output, post faders.

synth mode is off.

synth mode: play.

synth mode: seq.

synth mode: tone.



waveform: sine wave.

waveform: triangle wave.

waveform: square wave.

waveform: saw wave.

synthesis: kick drum.

synthesis: snare drum.

synthesis: hand clap.

synthesis: hi hat.

individual frequency / note control per track.

synthesis length or decay adjust.

trigger sequence pattern choice.

dj mode: off.

dj mode: fast cut.



dj mode: slow fade.

led brightness setting.

led brightness setting.

display brightness: low / medium / high.

theme: dark mode example.

ble on and accepting connection.

ble device naming.

usb ground noise suppression.

battery level / charging display.

factory reset function.

midi cc on.

midi cc off.

easter egg.